



HOW TO READ A REMOTE OUTSIDE VISUAL READER (OVR)

FIVE MOVEABLE WHEELS

TYPE OF REGISTRATION



PRINTED FIXED ZERO(S)

GALLONS [00] OR [000]
CUBIC FEET [0] OR [00]

NOTE: THE NUMBER OF
PRINTED FIXED ZERO(S) WILL
DEPEND ON METER SIZE AND
TYPE OF REGISTRATION
(SEE BELOW)

GALLON REGISTRATION -

5/8", 3/4", AND 1" SIZE REMOTES (OVR) READ IN INCREMENTS OF 100 GALLONS.
REMOTE (OVR) RECEIVES A PULSE FROM REGISTER ON METER EVERY 100 GALLONS.

1 1/2" AND 2" SIZE REMOTES (OVR) READ IN INCREMENTS OF 1000 GALLONS.
REMOTE (OVR) RECEIVES A PULSE FROM REGISTER ON METER EVERY 1000 GALLONS.

CUBIC FOOT REGISTRATION -

5/8", 3/4", AND 1" SIZE REMOTES (OVR) READ IN INCREMENTS OF 10 CUBIC FEET.
REMOTE (OVR) RECEIVES A PULSE FROM REGISTER ON METER EVERY 10 CUBIC FEET.

1 1/2" AND 2" SIZE REMOTES (OVR) READ IN CUBIC FEET INCREMENTS OF 100 CUBIC FEET.
REMOTE (OVR) RECEIVES A PULSE FROM REGISTER ON METER EVERY 100 CUBIC FEET.